

Переход 1000/600

Переход



	Единица измерения	Переход 1000/600
--	--------------------------	-------------------------

Размеры

d1	d2	l1	l2	L
1000	600	100	80	594

